

**BACKYARD
SAFARI™
OUT-FITTERS**

EXPEDITION TWO HIKING STICK



**5 YEARS
AND UP**

GET ON THE TRAIL! The EXPEDITION TWO kit features the unique Backyard Safari™ HIKING STICK. It's the perfect piece of personal gear that is indispensable on the trail. It has a cool hand-carved look on a sturdy natural looking walking stick that is a stout 45" tall. Helps keep a steady foot on the trail and is useful for poking and prodding those hard-to-reach places.

CONTAINS

1 HIKING STICK, 1 IRON-ON PATCH, 1 POP-UP FIELD GUIDE

USING THE HIKING STICK

- Take your Hiking Stick with you on hikes, long walks, or use it as a handy tool for exploring nature.
- Your Hiking Stick helps you up and down steep hills or through uneven terrain with added balance.
- Use the stick to keep from falling when you climb over large objects.
- Use the notches on the base of the Hiking Stick to grab things that are just out of reach, like a tree branch.
- Push objects out of your way, like spider webs or thorny bushes, with the base of your stick.
- Turn over logs and rocks to find lots of bugs and critters hiding underneath.
- Use the "spurs" on the base as hooks for a backpack. Hook your cargo, rest the stick on your shoulder, and off you go.
- Hang your backpack or other cargo on your Hiking Stick along your journey.
- Press the base into soft ground and use it as a backrest.
- Tie a bandana around the head of your Hiking Stick and wave it like a flag.
- In a pinch, your Hiking Stick can substitute for a tent pole.

FEATURES

- Prominent head with wild animal design
- Sturdy base with a hand-carved look
- Sculpted grips for comfort
- Natural wood look made of durable recycled plastic
- Handy notches along the base for hanging, carrying, and grabbing

CARING FOR THE HIKING STICK

Occasionally wipe the Hiking Stick with a damp cloth to keep it clean and looking new.

Use under normal and safe play conditions only.

When not in use, store the Hiking Stick in a clean and dry area. Occasionally, after use, inspect the Hiking Stick before putting it away.

Remember, if you follow the instructions and keep the Hiking Stick clean, it will provide you with tons of fun.

⚠ CAUTION, SAFETY AND CARE

The Hiking Stick is made of strong recycled plastic but do not leave your Hiking Stick outside or exposed to the elements.

Never swing it or use it to hit people or animals.

DO NOT USE THE HIKING STICK TO POKE HORNETS, BEES OR WASP HIVES!

DO NOT THROW THE HIKING STICK!

DO NOT USE THE HIKING STICK TO DISTURB BIRD'S NESTS OR HIVES OF ANY KIND, ANT MOUNDS OR THE HOME OF ANY ANIMAL.

SUMMIT™
Toys with a twist

© 2010 Summit Products, LLC
Birmingham, AL 35205
www.summittoy.com
PRINTED IN CHINA