



COUNTING MONEY JAR

Counting Money Jar Instructions

Saving money is easier than ever! Your new Counting Money Jar will count each coin you add to the jar so you will always know exactly how much money you have saved.

⚠ BATTERY CAUTION:

READ AND SAVE THESE INSTRUCTIONS.

Only adults should replace batteries. Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of old batteries promptly and properly. Do not burn or bury batteries.

Replace the batteries when the jar stops operating properly or the display becomes dim (Note: Removing the batteries will reset the account balance to zero). Batteries can leak chemicals and harm electronic parts, so remove them if you do not plan to use your jar for several weeks.

- Use only fresh batteries of the required size and recommended type.
- Never use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Be sure the batteries are inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

INSTALLING/CHANGING THE BATTERIES:

Your new Counting Money Jar requires 2 x 'AA' batteries (Not included). Remove the lid from the Jar carefully. Use a Philips screwdriver to loosen the screw on the battery compartment cover and lift the cover. Install 2 x 'AA' batteries into the compartment, being careful to match the polarity as indicated (+ and -). Replace the cover over the compartment and tighten the screw. Screw the lid back onto the Jar tightly.

DEPOSITING COINS:

Insert a coin into the slot in the top of the Counting Money Jar. The amount deposited will be displayed on the screen.

- To clear the account balance or reset the Counting Money Jar. The account will be reset to zero and \$0.00 will be displayed on the screen if the batteries are removed. You can also remove the lid from the Jar and press the Reset button to reset the balance to \$0.00.
- Keep the Counting Money Jar clean and dry. If any part of the Jar gets wet, wipe it dry immediately. Use and store the bank indoors, in environments which maintain normal temperatures.
- Handle the Jar carefully and do not drop it.
- Occasionally wipe the Jar with a damp cloth to keep it clean and looking new. Do not allow water in or near the electronic slot, as this may damage the device.
- Modifying or tampering with the Jar's internal components can cause it to malfunction and will void any warranty.

COMPLIANCE WITH FCC REGULATIONS:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SUMMIT™
Toys with a twist

© 2009 Summit Products, LLC.
Birmingham, AL 35205
www.summittoy.com
Made and Printed in China