



FIELD BINOCs



FIELD OF VIEW ADJUSTMENT



FOCUS RING

INSTRUCTIONS:

Adjusting Field of View:

Depending on the distance between your eyes, the field of view can vary from one person to another. In order to adjust the alignment between your eyes and the lens, hold your Backyard Safari Outfitters Field Binocs up to your face and look through the lenses. Do you see two images or one? If you see two images, rotate the two halves of your binocs around the center pivot back and forth until the two images you see come together to form a single view.

Adjusting Focus:

Now that you have adjusted your binocs' field of view, how does the image look? Is it clear, or is it blurry? Well, depending on how close, or how far away your viewing subject is, you may need to adjust the focus ring. Using the gray knob in the middle of your field binocs, adjust the focus by rotating this either left or right until the edges of the image you see is clear and sharp.

Cleaning Lenses:

Sometimes the lenses can get dusty, or you may accidentally touch them and leave a fingerprint which could prevent you from seeing the best image you can through your field binocs. Whenever this happens, just find a soft cloth or lens tissue, and gently wipe away any dust, dirt, or fingerprints. If the lens is extra dirty, you can use a lens-cleaning fluid, but make sure you use the fluid on the cloth and not directly on your binocs, or you may cause the lenses to fog up!