




# THE BUG WRANGLER'S MINI BUG VACUUM



## USING THE MINI BUG VACUUM

Find an insect that you would like to capture. Place the nose cone over the bug and squeeze the trigger.

Once the insect is inside the capture capsule, quickly close the trapdoor. The insect may be examined, released or transferred to the Bug Habitat (sold separately). Simply remove the transfer cap to the Bug Habitat, stick Mini Bug Vacuum nozzle in, and then open the trapdoor. Once the insect is safely inside the Bug Habitat, you may remove the nozzle and replace the transfer cap.



## CARING FOR THE MINI BUG VACUUM

Keep the Mini Bug Vacuum clean and dry. If it gets wet, wipe it dry immediately. Use and store the Mini Bug Vacuum in normal conditions only. Handle the Mini Bug Vacuum carefully and do not drop it. Occasionally wipe it with a damp cloth to keep it clean.

**SUMMIT**<sup>™</sup>  
*Toys with a twist*


© 2010 Summit Products, LLC.  
Birmingham, AL 35205  
www.summittoy.com  
Made and Printed in China

## CHANGING THE BATTERIES

The Mini Bug Vacuum requires 4 x 'AAA' size batteries (Included). We recommend using only alkaline batteries. Never use rechargeable batteries.

### Following these steps

1. Use a Philips screwdriver to loosen the screw on the battery compartment cover on the bottom of the handle. Remove the cover.
2. Remove the old batteries then put the new batteries into the compartment as indicated by the polarity symbols (+ and -) as marked inside.
3. Replace the cover and tighten the screw.



## ⚠ CAUTION

1. Only adults should replace batteries.
2. Replace the batteries when the Mini Bug Vacuum stops operating properly.
3. Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
4. Use only fresh batteries of the required size and recommended type.
5. Dispose of old batteries promptly and properly. Do not bury or burn old batteries.
6. If you do not plan to use your Mini Bug Vacuum for several weeks, remove the batteries. Batteries can leak chemicals that can harm electronic parts.
7. Rechargeable batteries are to be removed from the toy before being charged.
8. Rechargeable batteries are only to be chargeable under adult supervision.
9. Different types of batteries or new and used batteries are not to be mixed.
10. Non-rechargeable batteries are not to be recharged.
11. Remove exhausted batteries from the toy.
12. The supply terminals are not to be short-circuited.
13. Only the recommended batteries or equivalent are to be used.
14. Remove exhausted batteries from the product.
15. Do not use rechargeable batteries.
16. The battery installed in this product is for demonstration purpose only and the manufacturer makes no warranty as to the battery life.
17. Batteries are to be inserted with correct polarity.