

INSECT RESCUE KIT Instructions

Congratulations on getting your new Insect Rescue Kit! You are going to be an expert explorer in no time! So, let's get started...Diego might need some help!

CONTAINS

- 1 Butterfly net.
- 1 Rescue Vac.
- 1 Nature Pack.

USING THE INSECT RESCUE KIT:

Carefully remove your new Insect Rescue Kit from its package and check all the items for any cracks or damage. Everything okay? Great! One more thing....don't forget to read all the instructions thoroughly before use. So then, let's go over each item in your new Insect Rescue Kit one at a time and then you have to get busy...Diego needs your help!

First, the Butterfly Net. Okay, so your outside and you see a beautiful butterfly and you want to get a closer look. Well, with your Butterfly Net...carefully scope up the butterfly into the net. Remember, butterflies are fast and fragile, so you must be quick and careful! You're an explorer now and the care of any animal is important! So watch out for those beautiful, but delicate butterfly wings. Now, you can also use the Net to get a closer look at insects if you like, but remember, some bugs might bite or sting if they are scared, so stay away from bees and hornets Next....

The Rescue Vac


Find an insect you would like to rescue. Place the nose cone over the bug and squeeze the trigger until the insect has been pulled up into the rescue capsule. Use only enough vacuum power to gently pull the bug into the capsule. Once the insect is inside the rescue capsule, quickly close the trapdoor. Once the insect has been rescued, you may then safely examine the insect, release it or transferred it into the Nature Pack. If you're going to keep the insect, simply place the nose cone over the opening at the top of the Nature Pack, turn the knob to open the trapdoor and let the bug slide into the Nature Park. Don't forget to put the cover back on the opening and close the lid on the Nature Pack or all your hard work will be for nothing. Now, if you wish to release the insect, again, turn the

knob to open the trap door and let the insect crawl out. Last...

The Nature Pack. The Nature Pack is where you can safely keep your bugs and insects until you are ready to release them. Just follow the instructions above to place your insects inside. Now remember, these insects are now your responsibility, so you must keep them safe and make sure they have food and water. Don't over feed or water them though, that will make their house dirty and the insects won't like that. You do need to clean it out though. Just place your bugs in a safe container, gently pull the top of the Nature Pack off and was it out with water ONLY!

CARING FOR THE INSECT RESCUE KIT:

Keep the Insect Rescue Kit clean and dry. If any of the items do get wet, wipe them dry immediately. Use under normal, and safe play conditions only. When not in use, store the items in a clean, dry area and do not leave them exposed to the elements. When cleaning your Insect Rescue Kit NEVER use house hold cleaning products, not even window cleaner. ONLY WATER! Occasionally after use, wipe the Insect Rescue Items off with a damp cloth before putting it away. Also, don't forget to pay special attention to the Nature Pack. Remember, if you follow the instructions, keep the Insect Rescue Kit clean, it will provide you with tons of fun.



CHANGING/INSTALLING THE BATTERIES:

The Rescue Vac requires 4 AAA batteries, (not included). Alkaline batteries are recommended. Never use rechargeable batteries.

- 1.) Using a Phillips screwdriver, loosen the screw on the battery compartment cover on the underside of the handle. Remove the cover completely .
- 2.) Now, place the new batteries in the compartment as indicated by the polarity symbols.
- 3.) Replace the cover and tighten the screw.

CAUTION

Do not leave your Insect Rescue Kit outside or exposed to the elements.

Do not use or point the Rescue Vac or Butterfly Net at people or animals.

Do not try to pick up other small objects, such as coins, rocks with the Rescue Vac. It is intended only to be use on bugs and insects, trying to pick up other objects may clog the vacuum.

Keep the Nature Pack in a safe area, making sure to feed any bugs you keep. OR look, learn and then let them go safely back where you found them.

Do not use or point the Butterfly Net at people or household animals. The Butterfly Net is not to be used to chase your pets or people around the house.

Do not try to pick up other small object with the Butterfly Net. This toy is intended only to be use on Butterflies and insects, trying to pick up other objects may tear the net.

DO NOT USE THE BUTTERFLY NET to collect HORNETS, BEES or WASPS!

DO NOT USE THE BUTTERFLY NET to capture BIRDS, SQUIRELLS or ANY OTHER SMALL ANIMALS!

DO NOT USE THE BUTTERFLY NET to disturb BIRD"S NESTS or the home of any animal.

Do not catch any insect/bug that may bite or sting if frightened.

Be careful of sharp branches and twigs that may rip or tear the netting.

Do not use the BUTTERFLY NET if the net is torn or ripped

Lastly, remember you are using the Insect Rescue Kit to explore and learn about living creatures in nature. The Insect Rescue Kit is not to be used to harm or injure any living thing. If you do keep the bugs you catch, make sure to place them in the Nature Pack and provide them with food and water. Also keep the Nature Pack someplace where pets or younger brothers and sisters can't accidentally knock it over. OR look, learn and then let them go safely back where you found them. Remember, it is your responsibility to use the Insect Rescue Kit correctly. Always respect nature.

BATTERY CAUTION

Only adults should replace batteries. Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of old batteries promptly and properly. Do not burn or bury them.

Batteries can leak chemicals and harm electronic parts so, remove them if you do not plan to use your Rescue Vac for several weeks.

- Use only fresh batteries of required size and recommended type.
- Never use rechargeable batteries.
- Non-rechargeable batteries are not to be charged.
- Be sure the batteries are inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

SUMMITTM
Toys with a twist

© 2008 Summit Products, LLC.
Trussville, AL 35173

PRINTED IN CHINA

©2008 Viacom International Inc. All Rights Reserved.
Nickelodeon, Nick Jr., Dora the Explorer and all related titles, logos and characters are trademarks of Viacom International Inc.