



BOARDWALK BANKS



Saving money is now more fun than ever! From the beach boardwalk of the classic seaside resort, come these hilarious talking penny arcade replicas. Have "The Mystic Eye," answer a burning 'yes or no' question, or listen as "The Fortune Teller" gazes into your future, or just kick back and laugh with the comedic stylings of "Jester Joker" as he launches into one of his many routines.

Instructions:

⚠ BATTERY CAUTION: READ AND SAVE THESE INSTRUCTIONS.

Only adults should replace batteries. Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of old batteries promptly and properly. Do not burn or bury batteries.

Replace the batteries when the Boardwalk Bank stops operating properly or the lights and sounds becomes dim. Batteries can leak chemicals and harm electronic parts, so remove them if you do not plan to use your bank for several weeks.

- Use only fresh batteries of the required size and recommended type.
- Non-rechargeable batteries are not to be recharged.
- Be sure the batteries are inserted with the correct polarity.
- Exhausted batteries are to be removed from the bank.
- The supply terminals are not to be short-circuited.

INSTALLING/CHANGING THE BATTERIES:

Your new Boardwalk Bank requires 2 x 'AA' batteries (included). Remove the battery cover from the back of the bank carefully. Using a phillips-head screwdriver, loosen the screw on the battery compartment and lift the cover. Install 2 x 'AA' batteries into the compartment, being careful to match the polarity as indicated (+ and -). Replace the cover over the compartment and tighten the screw.

DEPOSITING COINS:

Insert a coin into the slot in the top of the Boardwalk Bank. The coin will activate any one of many pre-programmed skits or responses, along with lights and/or sounds.

- Keep the Boardwalk Bank clean and dry. If any part of the bank gets wet, wipe it dry immediately. Use and store the bank indoors, in environments which maintain normal temperatures.
- Handle the Boardwalk Bank carefully and do not drop it.
- Occasionally wipe the Boardwalk Bank with a damp cloth to keep it clean and looking new. Do not allow water in or near the electronic slot, as this may damage the device.
- Modifying or tampering with the Boardwalk Bank's internal components can cause it to malfunction.

COMPLIANCE WITH FCC REGULATIONS:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference,
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: Please remove all wire tie before use.

SUMMIT[™]
Toys with a twist

© 2010 Summit Products, LLC.
Birmingham, AL 35205
www.summittoy.com